


## Customer Set Up 20x40 Tents





## **Set-Up Instructions:**

- 1. Lay the tent top on ground with the web reinforced side down.
- 2. Square off all 4 corners and pull fabric straight and taut.
- 3. Measure 5 feet from tent at each jumper rope and drive the stakes with hook to outside of the tent.
- 4. Loop the rope from the wood slider over the hook on the stakes.
- 5. Stand the poles into the corners of the tent. Be sure the point goes through the grommet *and* D-ring.
  - a. Tighten rope slider enough to keep pole from falling over.
  - b. Repeat with balance of the perimeter poles. (It helps to leave the bottoms tipped towards the inside.)
- 6. Install the center pole(s).
  - Tie off jump rope and stand poles vertically.
- 7. Stand perimeter poles to straight. Tighten jumper ropes by pulling up sliders.
- 8. Hang sidewalls (optional).

For questions or additional help you can call us during store hours at 231-737-7368 or after hours at 231-740-5622