




Popcorn Machine



OPERATIONAL TIPS

SWITCHES:

- Light and Warmer Switch--- turns on heat lamp and optional strip heater under corn pan.
- Kettle Motor Switch--- turns on the motor that drives the kettle agitator shaft.
- Kettle Heat Switch--- turns on the heat element inside the kettle.

NOTE: Do not cover air vent holes! Motor air intake and exhaust holes at top of the machine must be clear of any obstruction.

POPPING INSTRUCTIONS

1. Turn on kettle heat, kettle motor, and exhaust switches. Let the kettle heat for 4 minutes.
2. When corn has popped, rotate the handle to empty popcorn from the kettle; return the kettle to an upright position.
3. Repeat the cycle; subsequent batches are always more flavorful than the initial batch.
4. Turn off the kettle heat switch on the final batch when the popcorn breaks over the lid of the kettle to eliminate smoke and odor.
5. Turn off the kettle motor and exhaust switches.
6. Wipe the exterior of the kettle with heavy cloth after cooling the kettle to prevent burn or stain of oil drippings.
7. Turn off all switches.

CLEANING INSTRUCTIONS

1. Allow the kettle to cool until warm enough to handle.
2. Unplug the kettle and remove it from the machine.
3. Remove popped corn and pack in bags.
4. Empty the un-popped kernel tray.

For questions or additional help you can call us during store hours at **231-737-7368** or after hours at

231-672-0641 Check out other items to rent at **RediRental.com**

Check out our "Redi Rental Popcorn Machine Tutorial" Video at: <https://www.youtube.com/watch?v=ik8gJmPMMO4>